

EXTERIOR TIMBERS

STEP 1 ► PREPARE

New Timber – Clean with CUTEK® Restore as per manufacturer instructions

Previously Coated Timber – Strip coating with CUTEK® Wood Stripper to remove the previous coating and clean with CUTEK® Restore as per manufacturer instructions.

STEP 2 ► PROTECT

Apply minimum of 2 coats of your chosen CUTEK® timber oil (CUTEK® Extreme CD50 or CUTEK® Wood Preservative) with CUTEK® Colourtone (if desired), allowing ample time for the oil to penetrate and dry between coats.

For maximum timber protection, we recommend 2 coats of CUTEK® Wood Preservative.

For maximum colour retention, we recommend 2 coats of CUTEK® Extreme CD50 with double CUTEK® Colourtone

Maintenance

PREPARE: Clean with CUTEK® Quickclean as per manufacturer instructions

PROTECT: Apply 1 x coat of your chosen CUTEK® timber oil (CUTEK® Extreme CD50 or CUTEK® Wood Preservative) with CUTEK® Colourtone (if desired)

INTERIOR TIMBERS

STEP 1 ► PREPARE

New Timber – Lightly sand timber surface using 180 grit sandpaper before cleaning the surface with mineral turpentine.

Previously Coated Timber – Lightly sand timber surface using 180 grit sandpaper before cleaning surface. Test adhesion of CUTEK® Interior to surface prior to full coating.

STEP 2 ► PROTECT

Apply minimum of 2 coats of CUTEK® Interior as per manufacturer instructions.