

CUTEK® QUICKCLEAN



CUTEK® Quickclean is a powerful general-purpose outdoor cleaner that removes dirt grease and grime from all your exterior hard surfaces.



Powerful outdoor cleaner – general-purpose cleaner that removes dirt, grease and grime from outdoor surfaces



Perfect for regular timber cleaning – prepares timber for a maintenance coat of CUTEK® Extreme CD50



Clean up CUTEK® spills with ease – easily cleans accidental spills of CUTEK® exterior timber oils



Cleans all hard surfaces – including composite decking, plastic, PVC, tiles, pavers, concrete and glass.

CUTEK® Quickclean will easily remove dirt, grease, and grime as well as even out CUTEK® Colourtone that has started to wear or erode unevenly on your wood.

It is the perfect way to regularly keep all your wood clean, and it prepares wood to optimise the performance of maintenance coats of CUTEK® Extreme CD50.

CUTEK® Quickclean is a concentrate that should be diluted with water. The dilution will vary depending on the build-up of dirt/grease on the surface.

CUTEK® QUICKCLEAN

COVERAGE & DILUTION

PURPOSE	DILUTION (RECOMMENDED)	COVERAGE
Remove grease, oil, dirt and grime	1:8 1 part CUTEK® Quickclean to every 8 parts water	4-7 sqm/L (diluted)

IMPORTANT: These figures represent typical averages for common decking and cladding species and are to be used as a guideline only.

IMPORTANT INFORMATION

CUTEK® Quickclean is a powerful general-purpose outdoor cleaner. It easily removes dirt, grease and grime and is the perfect way to clean your timber for a maintenance coat of CUTEK® Extreme CD50.

It is important for the user to pre-determine the suitability of CUTEK® Quickclean for its intended application. ALWAYS do a test area prior to applying to any large sections. As surface types and conditions can vary significantly, pre-testing will enable you to accurately estimate the dilution, time and amount of CUTEK® Quickclean required to complete your project, and enable you to perfect the cleaning technique that works best in your situation.

CUTEK® Quickclean is a powerful general-purpose outdoor cleaner that should be diluted. Dilution can vary depending on the type of surface being cleaned and the build-up of dirt/grease on the substrate. Always pre-test prior to making a full mixture to determine if dilution being used is effective in cleaning on your specific surface.

NOTE: Not all stains can be removed with CUTEK® Quickclean. To rejuvenate grey, weathered timber or to remove stubborn stains such as iron stains, water marks, tannins, resins, mould and fungus etc. you will need to use CUTEK® Restore.

CUTEK® Quickclean will not remove film coatings.

PRECAUTIONS

Before you begin to Prepare and Protect your timber, note the hazards and precautions and ensure that you have obtained and know how to use the correct safety equipment. CUTEK® Quickclean is a hazardous chemical. It is important to refer to the health and safety considerations listed in the Safety Data Sheet (SDS) prior to commencement of your project.

When using CUTEK® Quickclean all adjacent surfaces and vegetation must be adequately protected. It is also important to be aware of the potential for damaging wind drift into areas with cars or pedestrian traffic when rinsing. Water flush all equipment, vegetation, paths, concrete, asphalt and other adjacent surfaces before and after contact.

DO NOT SWALLOW

A full list of precautions and the SDS is available at www.cutek.co.nz